



# REMOTE CONTROL

FRIZ Light on

FRIZ Light off

Switch between two groups:  
e.g. CAN (ID group 11) and  
CUBE (ID group 44); TABLE uplight  
(ID77) and TABLE downlight (ID88)

Change color  
Cooler white tone  
Slower speed

brighter

Change color  
Warmer white tone  
Faster speed

darker

Choose saved mode  
shortcuts 1 | 2 | 3 | or 4

Key combination  
|Mode| - |+| or |-|, to  
switch between  
modes

Key combination  
|Match| - |Number| - |ID|,  
to assign ID

Microphone mode off  
Microphone mode on

Key combination  
|Number| - |ID| - |SR|,  
to search for ID

Keyboard light on

Flash mode on

Flashes when battery  
runs out

Race light mode on